


Yearly Average Relative Humidity Zones for the Continental United States.

If your air compression system is operating in zones 1, 2 or 3 then you have a water build-up problem. If you are operating in zone 4 you most likely have a problem. You may not be aware of it, but water within your compressed air system is rusting the inside of your receiver tank and piping, it's damaging the internals of your expensive air tools, gumming up air cylinders & pneumatic controls, fogging your painted surfaces, contaminating processes and clumping your blasting media. All of these problems cost you money, rework and down time. Air Options dryers can solve all of these problems. For more information about solving your water build-up problems, call and talk to one of our sales engineers @ 713-721-9619 or e.mail us at: Info@Air-Options.com.



P.O. Box 35984
Houston, Texas 77235
Ph.: 713-721-9619 Fax.: 713-726-1931
E.Mail: Info@Air-Options.com

AIR-OPTIONS, INC.

Affordable Solutions for Compressed Air